


# ARIGATO

Floor lamp, Table lamp, Ceiling lamp, Wall lamp



To tighten or loosen the Arigato arm joint (this applies to all Arigato arm joints):

- 1** Unscrew the small allen bolt (**A**) with 1.5 mm key.
- 2** Then tighten or loosen the big allen bolt (**B**) with 4 mm allen key.
- 3** When you are happy with the strenght of the joint - tighten back the small allen bolt (**A**) with the 1.5 mm allen key.

manufacturer:

**GRUPA STUDIO d.o.o.**  
**ZAGREB, CROATIA**

[www.grupaproducts.com](http://www.grupaproducts.com)  
[info@grupaproducts.com](mailto:info@grupaproducts.com)