


Anleitung:

Knapstein
G E R M A N Y

21.842.05 LENE

13 W LED, 2.700 K, Ra >90

Energieeffizienzklasse E



Montage:

Der Anschluß der Leuchte darf nur vom Fachpersonal ausgeführt werden!
Vor der Installation ist die elektrische Anlage spannungsfrei zu schalten!
Zuerst den silber lackierten Befestigungsbügel an der Wand befestigen,
dann den Trafokasten mit der angehängten Leuchte montieren

Gestensteuerung:

Die Wandleuchte ist mit einer Gestensteuerung ausgestattet. Der dazugehörige Sensor befindet sich in der Mitte des oberen Leuchtbandes. Innerhalb des Erfassungsbereichs (erkennbar durch Aufblinken der Funktions-LED) werden Bewegungsrichtung und Position der Hand durch einen Sensor erfasst. Durch eine wischende Bewegung im Sensorbereich wird die Leuchte an- bzw. ausgeschaltet. Verweilt die Hand längere Zeit unterhalb bzw. oberhalb des Sensors, wird die Dimmfunktion aktiviert und die Helligkeit lässt sich regeln.

Aber die Leuchte kann auch gedreht werden, so dass sich der Dimmer dann unten befindet.

Das integrierte Modul unterliegt keinem Verschleiß.

Fremdlicht oder Infrarot-Fernbedienungen beeinträchtigen die Funktion in keiner Weise.

Pflege der Leuchten:

Unbedingt vorher erst die Leuchte ausschalten und ca. 10 Minuten auskühlen lassen.

Zur Pflege der Leuchten benutzen Sie bitte ein weiches, trockenes Baumwolltuch.

Starke Verschmutzungen entfernen Sie bitte mit einem stark ausgewrungenen, leicht feuchten Fensterleder.

Verwenden Sie auf keinen Fall Reinigungsmittel oder chemische Zusatzstoffe, da diese die Oberfläche und Lackschicht der Leuchte beschädigen könnte.

12/2021



manual

Knapstein
G E R M A N Y

21.842.05 LENE

13 W LED, 2.700 K, Ra >90

energy efficiency class E



The connection of the light may be explained only by a specialist staff.

Before the installation the electric arrangement is to switch free of tension !

Fasten first the silver varnished connection hanger to the wall,
then mount the transformer box with the suspended light.

Gesture controlling:

The wall light is equipped with a gesture control. The corresponding sensor is located in the centre of the upper light band. Within the detection range (recognisable by the function LED flashing), the direction and position of the hand are direction of movement and position of the hand are detected by a sensor. A wiping movement in the sensor area the light is switched on or off. If the hand remains below or above the sensor for a longer period of time, the dimming function is activated and the brightness can be adjusted.

But the luminaire can also be turned so that the dimmer is then at the bottom.

The integrated module is not subject to wear.

Extraneous light or infrared remote controls do not impair the function in any way.

Care of the lamp:

Absolutely before: switch off the lamp and cool down approx. 10 minutes

To the care of the lamps you use please a soft, dry cotton cloth. You remove strong soiling please with a very wrung out, slightly humid chamois.

Use by no means cleaning agent or chemical additives, because this could damage the surface and varnish layer of the lamp.

12/2021